

Thera-Paw Boot Measurements

| Boot Size | Paw Width (cm) | Paw Length (cm) | Paw Circumference* (cm) | Carpus (wrist) or Hock (ankle) circumference* (cm) | Carpus (wrist) or Hock (ankle) height* (cm) |
|-------------------------|----------------|-----------------|-------------------------|----------------------------------------------------|---------------------------------------------|
| T/B—Small | 5.1 | 6.4 | Up to 7.6 | Up to 7.6 | 5.1 |
| T/C— Small/Med 1 | 5.7 | 7.0 | Up to 10.1 | Up to 8.9 | 6.4 |
| T/D—Small/Med 2 | 6.4 | 7.6 | Up to 14.6 | Up to 11.4 | 6.4 |
| T/E—Medium (new sizing) | 7 | 8.9 | Up to 17 | Up to 14.6 | 7.6 |
| T/F—Med/Large | 7.6 | 9.5 | Up to 17.1 | Up to 12.7 | 8.9 |
| T/G—Large | 8.9 | 10.8 | Up to 19 | Up to 15.2 | 10.1 |

Please view measurement instructions diagram for correct measurement placement.

https://www.reddogrehab.co.nz/uploads/1/1/8/8/118889065/thera-paw_boot_measurements.pdf