


Toe-up Sling Measurement guide and sizing



- Measure the circumference around the tarsus/hock joint (just above the bulbous part of the back of the hock)
- This measurement will correspond with the Toe-Up size (portion that wraps around the hock).

TOE-UP CUFF	SIZE (INCHES)	SIZE (CM)
X-Small	1"-3"	2.5 cm-7cm
Small	2"-4"	5 cm-10cm
Medium	4"-6"	10cm-15cm
Large	6"-8"	15 cm-20cm